8BitDo°

Retro Receiver for NGC - Instruction Manual








































NGC

Windows

01

02






· Please update the firmware of the controller and the receiver to the latest version.

8BitDo Mod Kit for Original NGC Controller


- 1. With the controller off, press and hold **B+START buttons** for 3 seconds to enter its pairing mode,
- the **Status LED** blinks rapidly. (This is required for the very first time only) 2. Connect the NGC receiver to the controller port of NGC console.
- 3. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 4. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - START/PAUSE A (c)




Ultimate 2.4G Controller

- 2. Press the Home button to turn on the controller
- 3. Hold the **Profile button** for 5 seconds to switch to Bluetooth connection. (The controller will vibrate once) 4. Hold the **Star button** for 3 seconds to enter its pairing mode, the **Status LED** will start to blink rapidly.
- (This is required for the very first time only)
- 5. Connect the NGC receiver to the controller port of NGC console.

 6. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly.
- 7. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.




- 1. Turn the Mode switch to BT position. 2. Press the **Home button** to turn on the controller.
 3. Hold the **Pair button** for 3 seconds to enter its pairing mode, the **Status LED** will start to blink rapidly.
- (This is required for the very first time only)
 4. Connect the NGC receiver to the controller port of NGC console.
 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
- 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



Ultimate 3-mode Controller for Xbox 1. Turn the **Mode switch** to **BT** position.

- Press the Xbox button to turn on the controller.
 Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only) 4. Connect the NGC receiver to the controller port of NGC console
- 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
- START/PAUSE



1. Press the **B+Start buttons** to turn on the controller. 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side.

SN30 Pro+ Bluetooth Gamepad

- (This is required for the very first time only)
 3. Connect the NGC receiver to the controller port of NGC console
- 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.

START/PAUSE

() • **(-) ()** @ (((<u>•</u>) 0


SN30 Pro for Android 1. Press the Xbox button to turn on the controller.

- 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only)
- 3. Connect the NGC receiver to the controller port of NGC console 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly.

 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - <u>•</u> • \bigcirc <u>•</u> 0 LS RS

Lite SE

- 1. Turn the **Mode switch** to **D** position. 2. Press the **Home button** to turn on the controller. 3. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side. (This is required for the very first time only)
 4. Connect the NGC receiver to the controller port of NGC console
- 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.




4. Press the Pair button of the receiver, the Status LED starts to blink rapidly. $5. The \, \textbf{Status LED} \, \text{of the controller and the receiver will remain solid to indicate a successful connection}.$



- ® • START/PAUSE





2. Connect the NGC receiver to the controller port of NGC console.


- 1 With the controller off, press and hold Share+PS buttons for 3 seconds to enter its pairing mode, the Status LED blinks rapidly. (This is required for the very first time only)
- 3. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 4. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.
- START/PAUSE




- 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
- <u></u> Θ 0




- START/PAUSE
- 9






START/PAUSE

- 1. With the controller off, press and hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side. (This is required for the very first time only)



Ultimate Bluetooth Controller


- Turn the **Mode switch** to **BT** position.
 Press the **Home button** to turn on the controller.
- 3. Hold the **Pair button** for 3 seconds to enter its pairing mode, the **Status LED** will start to blink rapidly. (This is required for the very first time only)
 4. Connect the NGC receiver to the controller port of NGC console
- 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
- 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



1. Press the **Home button** to turn on the controller.

Ultimate C Bluetooth Controller

- 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only)
 3. Connect the NGC receiver to the controller port of NGC console
- 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.




1. Press the Home button to turn on the controller.

Ultimate 2C Bluetooth Controller

- This is required for the very first time only)

 (This is required for the very first time only) 3. Connect the NGC receiver to the controller port of NGC console 4. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly.
- 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - **® (** <u></u> • \odot



1. Turn the **Mode switch** to **D** position. 2. Press the Start button to turn on the controller.

- Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side.
 (This is required for the very first time only) 4. Connect the NGC receiver to the controller port of NGC console Press the Pair button of the receiver, the Status LED starts to blink rapidly.
 The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



1. Press the **B+Start buttons** to turn on the controller. 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side.

SN30 Pro Bluetooth Gamepad

- (This is required for the very first time only)
 3. Connect the NGC receiver to the controller port of NGC console 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - START/PAUSE \odot 56 • <u>-</u> LS RS

Lite 2 1. Turn the Mode switch to D position.

- 2. Press the **Home button** to turn on the controller.


 3. Hold the **Pair button** for 3 seconds to enter its pairing mode, the **Status LED** will start to roll side to side. (This is required for the very first time only)
- 4. Connect the NGC receiver to the controller port of NGC console.

 5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - Z 0 **(** (☆)

1. Turn the **Mode switch** to **X** position. 2. Press the **Home button** to turn on the controller. 3. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side.

Lite

- (This is required for the very first time only)
 4. Connect the NGC receiver to the controller port of NGC console 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
- START/PAUSE




5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.

4. Connect the NGC receiver to the controller port of NGC console

- 4

START/PAUSE



START/PAUSE

DualSense / DualSense Edge 1. With the controller off, press and hold Create+PS buttons for 3 seconds to enter its pairing mode, the **Status LED** blinks rapidly. (This is required for the very first time only)

4. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.

3. Press the Pair button of the receiver, the Status LED starts to blink rapidly.

 \bigcirc



- Xbox One / Xbox Series / Xbox Elite Series 2 / Xbox Elite
- 1. Press the Xbox button to turn on the controller. 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only) 3 Connect the NGC receiver to the controller port of NGC console

4. Press the Pair button of the receiver, the Status LED starts to blink rapidly.

Series 2-Core / Xbox Adaptive Controller


5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



Wii U Pro

- 4 The Status I FD of the controller and the receiver will remain solid to indicate a successful connection START/PAUSE






· Windows 10 (1903) or above is required


8BitDo Mod Kit for Original NGC Controller

- 1. With the controller off, press and hold **B+START buttons** for 3 seconds to enter its pairing mode, the
- Status LED blinks rapidly. (This is required for the very first time only)
- Connect the NGC receiver to the USB port of your Windows device.
 Press the Pair button of the receiver, the Status LED starts to blink rapidly.
- 4. The Status LED of the controller and the receiver will remain solid to indicate a successful connection




Ultimate 2.4G Controller

- 1. Turn the Mode switch to D position.
- 2. Press the Home button to turn on the controller.
 3. Hold the Profile button for 5 seconds to switch to Bluetooth connection. (The controller will vibrate once) Hold the Star button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This
 is required for the very first time only)
- 5. Connect the NGC receiver to the USB port of your Windows device.
- 6. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
 7. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.




1. Turn the Mode switch to BT position

- 2. Press the Home button to turn on the controller
- 2. Fress the nome button to turn on the controller.
 3. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly.
 (This is required for the very first time only) 4. Connect the NGC receiver to the USB port of your Windows device
- 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



2. Press the Xbox button to turn on the controller


- 1. Turn the Mode switch to BT position
- $3. \, \text{Hold the \textbf{Pair button}} \, \text{for 3 seconds to enter its pairing mode, the \textbf{Status LED}} \, \text{will start to blink rapidly}.$ (This is required for the very first time only) 4. Connect the NGC receiver to the USB port of your Windows device.
- 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 6. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.



1. Press the B+Start buttons to turn on the controller. 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side. (This is required for the very first time only)

3. Connect the NGC receiver to the USB port of your Windows device

4. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



1. Press the Xbox button to turn on the controller.

- Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only) 3. Connect the NGC receiver to the USB port of your Windows device.
- 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly.

 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - ((-) 0

Lite SE 1. Turn the Mode switch to D position. 2. Press the Home button to turn on the controller.


- 3. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side. (This is required for the very first time only) 4. Connect the NGC receiver to the USB port of your Windows device.

 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.

•

(0

(A) (<u>•</u>) D (13) R3 • <u></u>



Menu

LT




®



5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6.The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.

4.Connect the NGC receiver to the USB port of your Windows device.



- **Switch Pro**

1. With the controller off, press and hold the **Pair button** for 3 seconds to enter its pairing mode, the

Status LED will start to roll side to side. (This is required for the very first time only)



1. Turn the **Mode switch** to **BT** position.

Ultimate Bluetooth Controller

- 2. Press the Home button to turn on the controller.
- Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only) 4. Connect the NGC receiver to the USB port of your Windows device. 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.
 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - LT RT LB RB <u></u> 🖲 🏵 🥌 (•) (e) \odot


1. Press the **Home button** to turn on the controller

Ultimate C Bluetooth Controller

- 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to blink rapidly. (This is required for the very first time only)
- 3. Connect the NGC receiver to the USB port of your Windows device.

 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly.


 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.



1. Press the **Home button** to turn on the controller

- $2. \, \text{Hold the Pair button for 3 seconds to enter its pairing mode, the \textbf{Status LED}} \, \text{will start to blink rapidly.} \, \text{(This pairing mode)} \, \text{(This pairing mode$ is required for the very first time only)

 3. Connect the NGC receiver to the USB port of your Windows device.
- 4. Press the Pair button of the receiver, the Status LED starts to blink rapidly. 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
- IT



3. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side. (This is required for the very first time only)


- 4. Connect the NGC receiver to the USB port of your Windows device
 - As commercine not because it was ose point of your windows service.

 5. Press the Pair button of the receiver, the Status LED starts to blink rapidly.

 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.

2. Press the Start button to turn on the controller.

Menu




2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will start to roll side to side. (This is required for the very first time only) 3. Connect the NGC receiver to the USB port of your Windows device.

SN30 Pro Bluetooth Gamepad

1 Press the B+Start buttons to turn on the controller

- 4. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 5. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
 - RB **()** • <u>•</u> В <u>-</u>




is required for the very first time only)

Lite 2

LB

- 4. Connect the NGC receiver to the USB port of your Windows device.
 5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.
- LT RT


RB



is required for the very first time only) 4. Connect the NGC receiver to the USB port of your Windows device. 5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.

Lite

- LT
- RB **()**



5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.

View

LT

(-

4. Connect the NGC receiver to the USB port of your Windows device.

(Arcade Stick V3 1. Turn the Mode switch to X position. 2. Turn the **Connection switch** to **BT** position.
3. Hold the **Pair button** for 3 seconds to enter its pairing mode, The four **LEDs** will start to blink clockwise. (This is required for the very first time only)
4. Connect the NGC receiver to the USB port of your Windows device.
5. Press the **Pair button** of the receiver, the **Status LED** starts to blink rapidly. 6. The Status LED of the controller and the receiver will remain solid to indicate a successful connection.

LB

RT

RT

RB

 \mathbb{N}

DualSense / DualSense Edge 1. With the controller off, press and hold **Create+PS buttons** for 3 seconds to enter its pairing mode,

LT

2. Connect the NGC receiver to the USB port of your Windows device. 2. Commerches the Pair button of the receiver, the **Status LED** starts to blink rapidly.

4. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.

the Status LED blinks rapidly. (This is required for the very first time only)



2. Hold the Pair button for 3 seconds to enter its pairing mode, the **Status LED** will start to blink rapidly. (This is required for the very first time only) 3. Connect the NGC receiver to the USB port of your Windows device 4. Press the Pair button of the receiver, the **Status LED** starts to blink rapidly. 5. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection.

LT


LB

2. Connect the NGC receiver to the USB port of your Windows device.

LB

3. Press the Pair button of the receiver, the **Status LED** starts to blink rapidly.

4. The **Status LED** of the controller and the receiver will remain solid to indicate a successful connection. LT



With the controller off, press and hold the Pair button for 3 seconds to enter its pairing mode, the Status LED blinks rapidly. (This is required for the very first time only)

Safety Warnings:

Please always use batteries, chargers, and accessories provided by the manufacturer.

- The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
 Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
 Avoid crushing, disassembling, puncturing, or attempting to modify the device or its bettery, as these actions can be dangerous.
- · Any unauthorized changes or modifications to the device will void the manufacturer's warranty.
- Support • Please visit support.8bitdo.com for further information & additional support.

Α

Wii U Pro

02