


• 某些功能仅适用于部分国家或地区

电池


1

• AAA 电池 x 2




2

• 从遥控器背面底部上滑, 打开电池盖



3

• 把AAA电池放入指定位 / 电池仓




• 请不要将新电池和旧电池混合使用  
• 灯光快速闪烁表示电池电量低

技术支持



\* 请访问 support.8bitdo.cn 了解详细信息。




• Certain features are available only in certain countries and regions

battery


1

• AAA Battery x 2




2

• Slide the battery compartment cover upward to open it



3

• Insert into the battery case



• Do not mix old and new batteries  
• Low battery - backlight starts to blink rapidly

support



• please visit support.8bitdo.com for further information & additional support